




BEFORE LEAVING THE STEAMING BAY

Check your boiler certificate is current
and the following are working :-

- gauge glasses
- safety valves
- water pumps/injectors
- brakes
- whistle

- Complete the “Fit to Run” form.



*Queensland Society of Model and
Experimental Engineers Inc.*

PO Box 7041 Brendale Qld 4500
Email: secretary@qsmee.com.au
